




Sirius B

Black Cherry POCKET PC

Quick Setup Guide


Button layout

Port assignment




UNPACK

1. Ockel Sirius B Black Cherry
2. Universal adapter base
3. EU / US / UK adapter
4. HDMI cable
5. Quick setup guide
6. Warranty card




BACK

1. Power button



FRONT

1. DC Power input
2. HDMI output
3. USB 3.0 host
4. USB 2.0 host



LEFT

1. Microphone input
2. Stereo L/R output
3. Micro SD card slot

Setup


INITIAL SETUP PROCEDURE

1. Connect an HDMI display with the HDMI cable
2. Connect the HDMI cable with the Ockel Sirius B Black Cherry Pocket PC
3. Connect a mouse and/or keyboard
4. Connect the EU, US or UK adapter to the universal adapter base. (Depending on the country outlet standard)
5. Connect to a power outlet
6. Press the power button
7. Configure the operating system by following the on-screen instructions

Important: do not turn off your Ockel PC during this procedure!
Initial set-up might take up to 30 minutes to complete

Connection

CONNECT TO MONITOR OR TV




CONNECT TO KEYBOARD AND MOUSE




1. Connect to keyboard and mouse via USB
2. Connect to keyboard and mouse via Bluetooth/Wireless

CONNECT TO SPEAKERS (please use amplified speakers)



CONNECT TO POWER



1. Connect the EU, US or UK adapter to the universal adapter base. (Depending on the country outlet standard)

General instructions

SHUTTING DOWN OCKEL SIRIUS B BLACK CHERRY

Press the start button in the lower left corner of the screen.
Select Power > Shut down.

SAFETY INSTRUCTIONS

- Keep the product away from sharp objects.
- Don't place heavy objects on top of the product.
- Don't put any pressure on the product, don't bend the product.
- Don't use any (chemical or organic) liquids with the product.
- Keep the product away from heating sources.
- Always use the power adapter and power cable that were included with your purchase. Any other adapter or cable may affect the performance of your Ockel device and/or cause (permanent) damage.

CLEANING

Clean the product with a moist cloth. Don't use any chemical liquids or oil!

For more information on how to use Ockel Sirius B Black Cherry visit:
www.ockelcomputers.com/support